

KEY POLYMER

SPECIALTY ADHESIVES
AND
CHEMICAL COMPOUNDS

CORPORATION

17 Shepard Street, Lawrence, MA 01843
Tel: 978-683-9411 Fax: 978-686-7729

KEY SLIP-STOP MIXING INSTRUCTIONS

KEY SS-200, SLIP STOP

PART #SS-200

After pouring one part B container into one part A container, add the contents of one quart of SLIP-STOP. ***MIX FOR 5 MINUTES WITH THE STIR STICK PROVIDED AND FOLLOW THE FLOOR RESTORE APPLICATION INSTRUCTIONS.***

PLEASE NOTE: FLOOR RESTORE material containing SLIP-STOP should be re-stirred each time you pour additional material on the trailer floor. This will prevent SLIP-STOP from settling to the bottom of your FLOOR RESTORE Kit and ensure even distribution of product.

PACKAGING:

Two plastic quart containers weighing 2-½ pounds each; 5 pounds total weight for one FLOOR RESTORE Kit.

Six plastic quart containers packaged per box (enough for 3 FLOOR RESTORE Kits).

